

# Amazon Echo with Alexa

What do the Light Colours Mean?



**By Gary Eady**

**Access Technology Trainer at**

**Sensory Services by Sight For Surrey**

Do you know what your Echo device wants to tell you when it shows up certain lights? Here are some of the descriptions that you should become familiar with:

## **Solid Blue with spinning Cyan lights**

This means that the device is starting up!

## **All Lights Off**

This means that the device is on and is waiting for your request or instruction.

## **Solid Blue with Cyan Pointing in Direction of Person Speaking**

This means that Alexa is busy processing your request.

## **Alternating Solid Blue and Cyan**

This means that the device is responding.

## **Orange Light Spinning Clockwise**

This means that the device is connecting to your Wi-fi network.

## **Solid Red Light**

This means that you have turned off the microphones on your device. Press the Mute button on top of the device to turn the microphones back on.

## **White Light**

This means that you are in the process of adjusting the volume on your device.

## **Continuous Oscillating Violet Light**

This means that an error occurred during Wi-Fi setup.

## **Spinning Blue Light that Ends in a Solid Purple Light**

This means that Do Not Disturb is enabled.

## **Single flash of purple light after an interaction with Alexa**

This means that Do Not Disturb is active.

## **Pulsing Yellow Light**

This means that a Message or Notification is waiting for you. To check your messages, say "Alexa, play my messages", or "Alexa, what did I miss?".

## **Pulsing Green Light**

This means that you are receiving a call or Drop In on your device. To answer the call, say "Alexa, answer". To deny the call, say "Alexa, ignore".